

PYRO 1394 PCI Card

Upgrade Your Computer to FireWire



<http://www.adstech.com>

ADS Technologies - 12627 Hidden Creek Way - Cerritos - CA - 90703
Phone: 562.926.1928 - Fax: 562.926.0518 - Support: 562.926.4338

PYRO 1394 PCI Card Hardware Installation



Step 1

Power down your computer and disconnect the power cord. Be sure to remove the power cord completely from your computer as shown in the picture to the left.



Step 2

Remove each screw found on the back of the computer. Be sure to put the screws you removed in a safe place, as you will need them again when replacing the shell on your computer.



Step 3

Carefully remove the shell from your computer.



Step 4

With the power cable disconnected from your computer, touch the metal part of the case to ground yourself. This will discharge any static electricity from your body which can damage your computer.



Step 5

Locate an available PCI expansion slot. This will be in the area of your computer where other cards that look similar to the PYRO PCI card are installed.



Step 6

Visually confirm that the PYRO 1394 PCI Card will fit into the available slot you have chosen.



Step 7

If necessary, remove the knockout on the back of your computer which corresponds to the PCI slot you have confirmed as your selection. If there is a screw, place it in a safe place as you will be using it to attach the PYRO 1394 PCI Card.



Step 8

Push the PYRO 1394 PCI Card firmly into the PCI slot. Apply pressure as needed (but do not force the card) until the edge connector is completely sealed.



Step 9

Once the PYRO 1394 PCI Card is fully seated, the gold edge connectors are completely in the slot.



Step 10

Mount the PYRO 1394 PCI Card in place with a screw. Make sure the screw is firmly tightened so the PYRO 1394 PCI Card does not slide out of its seated position.



Step 11

Replace the computer's shell and screw it back in place with the screws you removed in step 2.



Step 12

Now that your PYRO 1394 PCI Card is installed and the shell is in place, you can safely connect the power cable. Now restart your computer and install the drivers from the CD.

Driver Installation for Windows

Step 1

To the left is a picture of the dialog box that will notify you that Windows has detected your new hardware.



Step 2

Windows will now automatically run the "Add New Hardware Wizard." Select the first option "Search for the best driver..." and click the "Next" button.



Step 3

You will now see a box that asks where you would like to search for the drivers. Select the "CD-ROM" option. Make sure you have the Windows 98 SE, Windows 2000, or Windows ME CD inserted in your CD-ROM drive. After you have done this, click on the "Next" button.



Step 4

After Windows locates your new driver on the Windows 98 SE, Windows 2000, or Win ME CD, it will ask if you would like to install the driver. Select the first option that says "The Updated Driver" then click the "Next" button.



Step 5

Windows will now inform you it is ready to install your new driver. Verify that the path is the same as the picture to the left. It should read

"C:\WINDOWS\INF\1394.INF"

Now click the "Next" button.



Step 6

Congratulations! You are now done with the driver installation. All that is needed from you now is to click the "Finish" button.

